

## Hodgdon Powder Bushings Chart

not a loading table, but rather a chart based on relative based on relative hole sizes, showing the approximate num grains dropped by Ponsness/Warren powder bushings.

n using powder bushings you should always verify you are dropping the correct amount with a re

When ordering, please use the bushing number on the left side of the chart.

	Clays	Int'l Clays	Univ. Clays	Lil-Gun	Tite-Wad	Long-Shot	HS-6	HS-7	H110
1AX				12.0					
2AX				12.7					
3AX				13.1					
1A									13.4
2A									14.3
3A				15.0		13.0	14.5	15.3	15.4
A				17.8		15.0	16.8	17.6	17.8
B				18.1		15.5	17.7	18.6	
C			12.5	19.6		16.5	18.5	19.5	
C1			13.0	20.1		17.0	19.4	20.4	
D			13.2	21.4		17.3	20.2	21.1	
D1		11.7	14.0	22.4		18.2	20.9	21.9	
E		13.1	15.7	25.2		20.7	23.5	24.6	
E1		13.7	16.2	26.5		21.6	24.5	25.7	
E2		14.4	17.2	27.0	14.7	22.8	25.7	26.9	
F	13.2	15.2	18.1	27.9	15.6	24.2	27.2	28.5	
F1	13.7	15.8	18.3		15.8	24.4	28.3	29.6	
F2	13.9	16.1	18.9		16.4	25.3	28.8	30.1	
G	14.8	17.1	20.2		17.4	26.8	30.5	32.0	
G1	15.1	17.3	20.6		17.7	27.1	31.1	32.5	
H	16.0	18.4	22.0		18.9	29.0	33.0	34.6	
I	16.8	19.4	22.8		19.6	30.0	34.7	36.3	
J	17.2	19.8	23.9		20.3	31.2	35.4	37.1	
J1	17.7	20.3	24.5		21.0	32.0	36.4	38.2	
K	18.0	20.7	24.8		21.3	32.5	37.1	38.8	
L	18.9	21.8	25.7		22.2	34.0	39.0	40.8	
M	19.8	23.6	26.8		23.4	35.7	40.8	42.7	
N	21.2	24.4	28.2		25.2	38.0	43.6	45.7	
O	21.5		28.5			38.5	44.1	46.2	
P	21.9					39.9	45.0	47.1	
Q						40.1			
R						41.8			
S						42.5			